



# Training Module # 4 Process Heating Systems Assessment Methodology



## Assessment Standard and Guidance

- An assessment standard has been developed by The American Society of Mechanical Engineering (ASME) in collaboration with the U.S. Department of Energy
- It is issued as ASME-EA-1-2009, "Energy Assessment for Process Heating Systems"
- The standard has a Guidebook that guides a user on how to use the standards and related technical information.





## Assessment Standard and Guidance

- The Guidebook, "Guidance for ASME EA-1, Energy Assessment for Process Heating Systems", is issued as document ASME EA-1G-2010 with ANSI designation: ASME TREA-1G-2010
- The U.S. Department of Energy has conducted more than 400 process heating assessments from 2005 to 2011 for all major industrial sectors.
- The assessment process is very similar to the standards mentioned above.





## US DOE's Energy Saving Assessment (System Type)

System Type (No. of SENAs)	Average Identified Source Energy Savings (MMBtu/plant per year)	Average Percent Source Energy Savings Identified (%)	Average Identified Cost Savings (\$/plant per year)	Average Natural Gas Savings Identified (MMBtu/plant per year)	Average CO2 Savings Identified (Metric Tons/plant per year)	Average Payback Period Identified (Years)
Compressed Air (174)	32,300	2.7	\$192,000	400	1,800	1.1
Fans** (50)	105,000	3.1	\$624,000	33,000	6,000	2.6
Process Heating (237)	218,600	7.7	\$1,474,000	167,200	12,400	1.5
Pumps (94)	38,800	1.2	\$210,000	1,000	2,300	1.7
Steam (343)	256,000	6.1	\$2,000,000	199,900	17,900	1.6
Multi-System- Paper (31)	354,900	5.2	\$2,259,000	173,200	18,600	0.5

<sup>\*\*</sup> Fan results are based on 48 ESAs instead of 50 ESAs. Two large outliers are not considered in this analysis.

Source: Based on Save Energy Now assessments conducted between 2006 to 2011. Numbers are as of October 1, 2011.





## TOP TEN FREQUENTLY IDENTIFIED PROCESS HEATING OPPORTUNITIES SAVE ENERGY NOW ASSESSMENTS - 2006 to 2011

Top Ten Frequently Identified Process Heating Opportunities (ESAs - 2006 to 2011)	No. of Times Identified	Average Energy MMBtu Savings Identified (Source)	Average Source Energy Savings % Identified (%)	Average Energy Cost Savings Identified (\$)	Average Energy Cost Savings % Identified (%)	Average of Payback Period Actual (yr)
Reduce oxygen content of flue (exhaust) gases	183	24,415	1.2	\$177,471	1.3	0.9
Use of flue or Exhaust gas heat for combustion air preheating	123	67,325	3.6	\$407,062	2.6	1.9
Proper insulation and maintenance of furnace structure or parts	120	24,476	1.0	\$166,469	1.1	1.4
Reduce-eliminate openings and air leakage in the furnace	76	20,343	1.1	\$154,529	1.3	1.0
Load or charge preheating using heat from flue or exhaust gas or other source of waste heat	72	30,173	1.5	\$245,646	1.8	2.0
Heat cascading - use of flue or Exhaust gas heat from higher temp. process to supply heat to lower temperature processes	61	53,680	2.1	\$407,020	2.3	1.5
Use of proper heating methods - replace inefficient and uneconomical methods with economical/efficient system	54	83,061	6.5	\$407,523	3.6	3.0
Heat recovery from hot products or other heat sources (i.e. from walls) from a furnace - oven	44	82,963	2.8	\$558,684	3.3	1.8
Furnace scheduling, loading, shut down - avoiding delays, waits, cooling between operations etc.	40	36,058	2.3	\$323,857	2.8	0.4
Use of oxygen for combustion	37	85,949	2.6	\$598,268	3.2	1.9






## Organizing the Assessment

- 1. Identification of assessment team members
- 2. Getting the plant support
- 3. Definition of assessment goals and scope
- 4. Assessment Plan of Action
  - Identification of equipment/system
  - Definition of data collection requirements and methods
  - Initial measurement plan: Where and when to collect data
  - Assessment schedule
  - Key personnel interviews






## Conducting the Assessment








## Conducting the Assessment







## Areas Considered for Process Heating Assessment







## Load – Charge Material

#### If Type of Material is: Solid

Name of material:

Charge (wet) - Feed Rate (lb/hr)

Water Content as Charged (%)

Water Content as Discharged (%)

Initial temperature (°F)

Charge material discharge temperature (°F)

Water vapor discharge Temperature (°F)

Charge Melted (% of Charge)

Charge Reacted (% of Dry)

Heat of Reaction (Btu/lb)

Endothermic/exothermic?

#### If Type of Material is: Liquid

Charge (Liquid)-Feed Rate (lb/hr)

Initial temperature (°F)

Discharge Temperature (°F)

Charge Liquid Vaporized (% of Charge)

Charge Liquid Reacted (% of Charge)

Heat of Reaction (Btu/lb)

Endothermic/exothermic?

#### If Type of Material is: Gas

Feed Rate for Gas Mixture (lb/hr)

Vapor in Gas Mixture (% of Total)

Initial temperature (°F)

Discharge Temperature (°F)

Specific Heat of Vapor (Btu/lb-F)

Feed Gas Reacted (% of Total)

Heat of Reaction (Btu/lb)

Endothermic/exothermic?





## Material Handling

#### Fixture, Trays, Baskets etc. Losses\*

Material Name (if necessary, give sp. heat below)

Fixture Weight- Feed Rate (lb/hr)

Initial temperature (°F)

Final temperature (°F)

Specific Heat of material (Btu/lb-F) - if required

## **Combustion Systems**

#### **Combustion System Information\***

Type of fuel used

Number of zones

The following information is given for EACH zone:

Number of burners

Size or firing rate of burners (MMBtu/hr) for ALL burners

Duty factor (as % of operating hours)

Load factor (as % of firing rate)





#### Flue – Exhaust Gases

#### Flue Gas Losses (for Fuel Fired Furnace only)

Furnace flue gas temperature (°F)

% oxygen in flue gas

% of excess air (%XS)

Combustion air temperature (°F)

Fuel temperature (°F)

Moisture in combustion air (%) – solid/liquid fuels
Ash discharge temperature (°F) – solid/liquid fuels
Unburned carbon in ash (%) – solid/liquid fuels
User defined fuel if not natural gas – need to
provide fuel composition

#### Wall Losses

#### **Wall Surface Heat Losses**

Average surface temperature (measured) (°F)

Ambient Temperature (°F)

Wind velocity (mph)

Surface shape/Orientation

Surface emissivity (default =0.9)

Total outside surface area (ft<sup>2</sup>)

Correction factor (based on local conditions)

Number of surfaces





### Opening Loss: Fixed and Variable

#### **Opening Losses (Rectangular)**

Number of openings of same size and shape

Average inside temp (°F)

Ambient temperature (°F)

Wall thickness or opening depth (in)

Length of Opening (L) (in)

Height of Opening (H) (in)

View factor - known or from chart

Emissivity of the source (Default=0.9)

% Open time (Default=100%)

#### **Opening Losses (Round)**

Number of openings of same size and shape

Average inside temp (°F)

Ambient temperature (°F)

Wall thickness or opening depth (in)

Diameter of Opening (in)

View factor - known or from chart

Emissivity of the source (Default=0.9)

% Open time (Default=100%)





## Water/Air Cooling

#### Water- or Air-Cooling Losses \*

Cooling Medium (Water, air, other liquid or gas)

Cooling Liquid Flow (gal/min)

Cooling Gas Flow (SCFM)

Inlet Temperature (°F)

Outlet Temperature (Below boiling point) (°F)

Specific heat of gas or liquid (Btu/lb-F) if required

## **Auxiliary Systems**

#### Fixture, Trays, Baskets etc. Losses \*

Material Name (if necessary, give sp. heat below)

Fixture Weight- Feed Rate (lb/hr)

Initial temperature (°F)

Final temperature (°F)

Specific Heat of material (Btu/lb-F) if required





#### Additional Information

#### **Atmosphere Losses\***

Type of gas

Initial temperature (°F)

Final temperature (°F)

Flow Rate (SCFH)

#### **Makeup Air Losses**

Initial temperature (°F)

Final temperature (°F)

Flow Rate (SCFH)

Specific heat (Btu/lb-F) of gas if required

## Other Losses (from extended or other surfaces of furnace)

Approx. Area (ft<sup>2</sup>)

Average temperature (°F)

Ambient temperature (°F)





## Furnace Flue Gas Analysis


- Flue gas analysis is used to identify burner combustion efficiency and presence of air leaks (if any) in a furnace or boiler.
- There are many different options for location where we should take flue gas analysis.
- The location depends on available ports for inserting the probes, presence of recuperator, economizer or other type of heat recovery system.
- Data of most interest for the flue gas analysis is flue gas temperature,
   % oxygen and % CO and/or combustibles. Other data can be collected but it is secondary interest for energy savings opportunities.





## Flue Gas Analysis

## No Recuperator or Economizer








## Flue Gas Analysis No Recuperator or Economizer

#### **Example of Actual Furnace**

Option 2







**Caution** 

Note high CO in flue gases.


**Contact technical specialist** for further discussions.





## Flue Gas Analysis

## With Recuperator/Economizer








## Flue Gas Analysis

## With Recuperator







### Wall Heat Losses

- Wall heat losses can be estimated by measuring furnace/boiler wall temperature and surface area.
- It is also necessary to take notice of any hot spots on the walls.
- The measurements involve use of an infra-red temperature measuring instrument (pyrometer or "gun") to measure temperature at key locations shown in the following slides.
- It is possible to use a contact thermocouple or a thermographic camera to get wall surface temperature distribution.
- Use the data sheets to collect data.
- It is not necessary to know details of the wall insulation (thickness, type, etc.)










## Wall Heat Losses




- 1. Measure temperatures at nine (or more) locations on a wall.
- 2. Measure dimensions of the area for which temperature is measured.





## Wall Heat Losses



- 1. Notice areas of hot spots areas where paint is peeled off, wall color is different or where hot gases are leaking out of the furnace.
- 2. Estimate or measure area of each of the hot spots and measure temperature at the center of such areas.





## Opening Heat Losses

- Opening heat losses can be estimated by measuring furnace/boiler inside temperature.
- It is necessary to measure or estimate dimensions (such as diameter, width, length) of the openings.
- It is also necessary to collect data for furnace/boiler wall thickness notice of any hot spots on the walls.
- The measurements involve use of an infra-red temperature measuring instrument (pyrometer or "gun") or you can use furnace/boiler temperature from the control panel or chart.
- Use the data sheets to collect data.





### Other Data


- For water- and air-cooling loss it is necessary to measure flows and inlet – outlet temperature for water or air. In most cases it is enough to collect data in the main inlet and outlet pipes.
- For other radiation loss measurement of exposed or open surface areas and temperature is enough.
- The burner information is collected by using existing drawings, manufacturer's operating manuals or actual name-plate data from the burners.
- The burner operating data requires fuel flow or other information that gives actual firing rate at average operating conditions. In some cases, it may be necessary to use "educated" estimates.





## Heat Balance Report

## **Current Operation**



MEASUR or other methods can be used to develop a heat balance for the heating equipment





## Savings Analysis - Energy

- Identify relatively large areas of heat loss. Use information discussed in Energy Efficiency Improvement section.
- Example:
  - In the heat balance shown in previous slides areas of "high" heat loss are flue gas loss, wall loss, and fixture heat loss.
- Possible improvements: Use information discussed in Energy Efficiency Improvement section to make recommendations for energy savings.
- Calculate energy savings using MEASUR or other similar methods.





## Savings Analysis - Other

- In many cases the energy saving projects may result into additional savings in areas such as:
  - Productivity increase
  - Higher product yield lower product losses
  - Improved product quality
  - Reduced emissions
  - Savings through lowering of "peak" rates
  - Reduction of operating and maintenance cost
- Total cost savings must include energy cost savings and other savings mentioned above.





## Savings Analysis and Report

- Perform preliminary cost analysis.
- Discuss applicability of recommendations with the assessment team and the plant personnel
- Select final acceptable recommendations.
- Prepare a draft report as per instructions given in the guidance document.
- Review draft report with the plant and after making suggested changes (if any) prepare a final report.





### **Guidance Document**

- The document provides an application guide on how to utilize ASME EA-1 Energy Assessment for Process Heating Systems.
- It gives detail information on:
  - Selection of measurement instruments (temperatures, flow, etc.)
  - Suggested data sheets for collecting the required information to prepare a heat balance.
  - Detailed instructions on conducting an assessment.
  - Instructions on presentation of results in the form of a table and charts.
  - Information on possible areas of energy savings or reduction of heat losses in process heating equipment.





## Acknowledgements

- Some material used in this presentation is obtained from ASME Process Heating Energy Assessment Standards.
- The ASME ANSI standards were developed by using contributions from Dr. Arvind Thekdi and Mr. Richard Bennett (both Co-chair for the committee) and review by a committee of more than a dozen individuals.
- We appreciate contributions by all these individuals who conducted assessments for the US DOE and contributed to the material used in this presentation.



